

WIRELESS 2- OR 4-WAY PUSHBUTTON 43 X 43 MM, WITHOUT FRAME, WITHOUT BATTERY AND WIRE FT4BI-



Wireless pushbutton with intermediate frame and rocker (without frame)



Wireless pushbutton with intermediate frame and double rocker (without frame)

enocean®

Manuals and documents in further languages:
https://eltako.com/redirect/FT4BI-

FT4BI-

Wireless 2- or 4-way pushbutton 43x43 mm. Generates the power for wireless telegrams itself when the button is pressed, therefore there is no connecting wire and no standby loss.

FT4BI-an	Wireless 2- or 4-way pushbutton 43 x 43 mm, without frame, without battery and wire, bticino anthracite	**Art. No. 30000245**	**62,00 €/pc.**
FT4BI-ww	Wireless 2- or 4-way pushbutton 43 x 43 mm, without frame, without battery and wire, bticino w.white	**Art. No. 30000246**	**62,00 €/pc.**

Recommended retail prices excluding VAT.