

Wireless pushbutton with rocker (without frame)



Wireless pushbutton with double rocker (without frame)

Manuals and documents in further languages:
https://eltako.com/redirect/FT55BT*EL-ws

FT55BT/EL-ws

Wireless 4-way Bluetooth pushbutton 55 x 55 mm Finland, elko white.

Wireless pushbutton insert with EnOcean energy generator. Generates the power for wireless telegrams itself when the button is pressed, therefore there is no connecting wire and no standby loss.

The scope of supply comprises the mounting base, an attachment frame for PTM moduls with EnOcean module inserts PTM216B and an adhesive foil.
The mounting plate can be screwed over a flush-mounting box with a screw spacing of 60 mm or screwed on a flat surface.The wireless pushbutton can be glued to the wall, on glass or on furniture using the enclosed adhesive foil.
Wireless pushbuttons with double rocker can transmit four evaluable signals: press two rockers up or down.

FT55BT/EL-ws	Wireless 4-way Bluetooth pushbutton Finland, without frame, elko white	**Art. No. 30000248**	**62,20 €/pc.**

ATTENTION: Not compatible with EnOcean wireless actuators!